




## CWT-BK series config tool instruction

### 1. Connect device


Connect device to computer by USB to RS485 port or Ethernet, and run the config tool




## 2. set parameters



Setup serial port parameters:



Setup Ethernet parameters:



After setup parameter, please restart (power off and on)