




CWT-BSR series config tool instruction

1. Connect device


Connect device to computer by USB to RS485 port, and run the config tool



2. set parameters



Setup serial port parameters:



After setup parameter, please restart (power off and on)